



KAPPA Special Edition allows you to expand the field of possibilities with High Curve function



KAPPA

SPECIAL EDITION

EVERYTHING THE NEXT-GENERATION KAPPA OFFERS AND MORE!

1 KAPPA SPECIAL EDITION RACE THROUGH WORKLOADS



- Automatic binocular tracing in 3 dimensions
- Bevel: 3D bevel preview and configurable bevel trajectory
- Grooving: configurable positioning, width and depth
- Chamfering: front face and/or back face, by flexible chamfering wheel
- Polishing: flat and bevel
- More ergonomic centering (wide open space)
- EAS (Edging Assisted System) cycle to avoid axis deviation on fragile lenses
- 1,000 positions job database

2 'HIGH CURVE' FUNCTION EXPAND THE FIELD OF POSSIBILITIES



- Base curve coverage to 8, for all materials except mineral, with adjustable bevel height, width and location
- Go for quality finished jobs instead of ill-fitted lenses and decrease the number of re-do's
- Dispense a greater variety of glasses with wrap-around frames

- To be able to trace, edge and mount with a KAPPA Special Edition edger, you need to add a Neksia, Mr. Orange or Mr. Blue tracer/blocker.
- Edging mineral lenses with KAPPA Special Edition is not possible.
- For further information and specifications on Neksia in particular, please consult the Neksia brochure



Essilor Instruments USA
8600 W. Catalpa Avenue, Suite 703
Chicago, IL 60656 - USA
Phone: 855.393.4647
Email: info@essilorinstrumentsusa.com
www.essilorinstrumentsusa.com